



GMDAPK3

All GM data controlled vehicles. Control of Passlock and PK3.
Interface module self-adjusts to various vehicle platforms.



Note: Connector 2 is to be wired only for and Cadillac or if the SECURITY light turned on after start, (see diagrams below).



PROGRAMMING SEQUENCE :

- 1 Locate and press the programming switch while inserting the wire harness into connector 1 of the GMDAPK3 module. The LED status indicator will illuminate to indicate you are in programming mode. Keep the programming button pressed while turning the ignition to the "ON" position. Release the programming switch once the LED status indicator flashes rapidly.
- 2 Start the engine (utilizing the vehicle key). The LED status indicator will turn off to indicate the module has been programmed for either PK3 or Passlock (and control of additional features where applicable). Turn the key to the "OFF" position. The module is now ready for use.

Note: The manufacturer/distributor is not responsible for any damages which may directly or indirectly result from the installation of this module. The manufacturer/distributor is limited to the repair or replacement of this module in the case of manufacturing defects.

Technical Support:

TEL: 514-255-0446 FAX: 514-255-1367
Web: <http://support.fortinautoradio.com>

Order Part Number: GMDAPK3

Version : 2.0
Revision : Dec. 22 2004

Made in Canada

Manufactured under US patent No.:

5,719,551	6,011,460 B1
6,243,004 B1	6,249,216 B1
6,275,147 B1	6,529,124 B2
6,696,927 B2	6,756,885 B1
6,756,886 B2	6,771,167 B1

Canadian patent No.:

2,320,248	2,415,023
-----------	-----------

European patent No.:

1,053,128

Vehicle	Years							PK3 or Passlock Bypass					
	98	99	00	01	02	03	04						05
GMDAPK3													
Bravada	•	•	•	•	•	•	•	•					
Envoy	•	•	•	•	•	•	•	•					
Trailblazer	•	•	•	•	•	•	•	•					
Rainier								•					
Avalanche	•	•	•	•	•	•	•	•					
Escalade	•	•	•	•	•	•	•	•					
C/K Pick Up	•	•	•	•	•	•	•	•					
Silverado	•	•	•	•	•	•	•	•					
Sierra	•	•	•	•	•	•	•	•					
Suburban	•	•	•	•	•	•	•	•					
Tahoe	•	•	•	•	•	•	•	•					
Yukon (all)	•	•	•	•	•	•	•	•					
Hummer	•	•	•	•	•	•	•	•					
	98	99	00	01	02	03	04	05					
Aurora			?	•	•	•	•	•	•				
Deville			?	•	•	•	•	•	•				
Allure								?	•				
Le Sabre			•	•	•	•	•	?	•				
Bonneville								?	•				
Park Avenue			?	•	•	•	•	?	•				
SRX								?	•				
SLS			?	•	•	•	•	?	•				
CTS								?	•				
STS				•	•	•	•	•	•				
ESV									•				
EXT								?	•				
XLR									•				
	98	99	00	01	02	03	04	05					
Alero	•	•	•	•	•	•	•	•	•				
Astro & Safari	•	•	•	•	•	•	•	•	•				
Blazer	•	•	•	•	•	•	•	•	•				
Cavalier & Sunfire	•	•	•	•	•	•	•	•	•				
Express & Savana	•	•	•	•	•	•	•	•	•				
Grand Am	•	•	•	•	•	•	•	•	•				
MonteCarlo	•	•	•	•	•	•	•	•	•				
Intrigue	•	•	•	•	•	•	•	•	•				
Sonoma & S-10	•	•	•	•	•	•	•	•	•				
Colorado									•				
Canyon									•				
Saturn Série S			•	•	•	•	•	•	•				
Saturn ION													
Saturn VUE													
	98	99	00	01	02	03	04	05					
Astek				•	•	•	•	•	•				
Grand Prix													
Montana				•	•	•	•	•	•				
Rendez-vous				•	•	•	•	•	•				
Silhouette				•	•	•	•	•	•				
Venture				•	•	•	•	•	•				
Uplander				•	•	•	•	•	•				
	98	99	00	01	02	03	04	05					

• -- TESTED and functional.
? -- Not TESTED on all series of each models, but should be functional.

Option 2: Connect the yellow wire (connector 1) to ignition. This is a mandatory connection for vehicles in this category.